

Fibreboard Method Statement (Bitumen impregnated boards)

Section A : General Comments

Equipment

It is suggested that the following list of equipment is adopted as a minimum requirement:

<i>Personal protection</i>	:	<i>Protective overalls</i> <i>Gloves and goggles</i>
<i>Equipment</i>	:	<i>Nails</i>
	:	<i>Hammer</i>
	:	<i>Cutter blade</i>

Section B : Application

1.0 Surface Preparation

- 1.1 The concrete substrate should be fully cured, dry, clean and free from laitance or any other contaminations and projections.
- 1.2 Cut the Fiberboard to the required dimension.

2.0 Application for Expansion joints

- 2.1 Align the Fiberboard against the shuttering to the concrete side.
- 2.2 Nail the Fiberboard in place to avoid displacement during pouring of the concrete or in suspended slabs. Special adhesive can also be used instead of nails.
- 2.3 Cut the top side of the board before pouring of the concrete to provide the required joint depth, in accordance with the design and movement requirements.

Section C : Approval and variations

This method statement is offered by DCP as a 'standard proposal' for the application of **Fiberboard**. It remains the responsibility of the Engineer to determine the correct method for any given application. Where alternative methods are to be used, these must be submitted to DCP for approval, in writing, prior to commencement of any work. DCP will not accept responsibility or liability for variations to the above method statement under any other condition.



expertise



quality



full range