

Setseal 100C Method Statement (Acrylic cement modified one component waterproof coating)

Section A : General Comments

High temperature working

- (i) Unmixed materials and the equipment should be stored in a cool place and out of direct sunlight.
- (ii) Plan for enough material, tools and labours to avoid any stop while the application process.
- (iii) Avoid application through peak temperatures of the day.

Equipment

It is suggested that the following list of equipment is adopted as a minimum requirement:

<i>Protective clothing</i>	:	<i>Good quality gloves, goggles and protective overalls</i>
<i>Mixing equipment</i>	:	<i>Heavy duty mixer, Mixing paddle and empty bucket (25 litre)</i>
<i>Application equipment</i>	:	<i>Short haired roller or soft bristled brush</i>

Section B : Application

1.0 Surface Preparation

- 1.1 Surface should be clean and free from any laitance, wax, grease, dirt and oil or contamination which could affect the bond.
- 1.2 Suitable mechanical cleaning methods such as water jet or sand blasting should be used to remove any existing old coating or surface treatments like curing compounds.
- 1.3 All cracks and spalled concrete should be repaired before starting the application as recommended by our technical department.
- 1.4 Presoak the concrete surface with water prior to Setseal 100C application until a surface saturated dry condition is reached.
- 1.5 Remove any excess water by sponge prior to the application.

2.0 Mixing

- 2.1 Pour 4.7 litre of clean water for every 15 kg bag of Setseal 100C in suitable clean bucket and start adding the powder gradually while continuous mixing is maintained.
- 2.2 Use slow speed mixer fitted with mixing paddle to mix the powder and water.
- 2.3 Time of mixing should be between 3 - 5 minutes or until lump-free slurry is obtained.



expertise



quality



full range

- 2.4 Do not mix part of packs under any condition, as this will change the mixing ratio between the powder and water which will affect the material performance.

3.0 Application

- 3.1 Apply the mixed material using a soft brush or roller.
- 3.2 Apply the first coat into the concrete surface at wet film thickness of 1 mm.
- 3.3 Allow 3 - 5 hours for curing at temperature of 30°C before applying the second coat in a well ventilation surfaces. For limited ventilation or at low temperature, allow 24 - 48 hours before applying the second coat.
- 3.4 Apply the second coat at wet film thickness of 1 mm but in a direction perpendicular to the first coat.
- 3.5 To achieve smooth finish, it is recommended to finish the surface with a plastic or steel trowel **immediately** after applying the second coat.
- 3.6 Allow 4 - 7 days depending on ventilation and ambient temperature after applying the second coat for full curing before water immersion.

4.0 Cleaning

- 4.1 Use clean water to clean the tools within the pot life of the material.

Section C : Approval and variations

This method statement is offered by DCP as a 'standard proposal' for the application of **Setseal 100C**. It remains the responsibility of the Engineer to determine the correct method for any given application. Where alternative methods are to be used, these must be submitted to DCP for approval, in writing, prior to commencement of any work. DCP will not accept responsibility or liability for variations to the above method statement under any other condition.



expertise



quality



full range